


TAPPATRICE 3 LEVE "GILDA" PER TAPPI SUGHERO



Componenti e composizione materiali

- Registro.
- Corpo centrale in nylon.
- 4 ganasce mobili.

Confezionamento

- Master: 20pz in scatola 51x37,5x26,5

Utilizzo


Per tappi in sughero di diametro massimo 24mm.

Istruzioni d'utilizzo

1. Girare la tappatrice in modo che la leva si trovi al di sotto del corpo per evitare la fuoriuscita del tappo.
2. Allontanare i manici per allargare lo spazio dove andrà poi inserito il tappo.
3. Tirare verso l'alto la leva, per far spazio al tappo.
4. Inserire il tappo.
5. Stringere bene i due manici.
6. Girare la tappatrice.
7. Appoggiare sulla bottiglia.
8. Abbassare la leva con decisione.

Istruzioni di montaggio

1. Inserire con un colpo secco il punzone "C" all'interno dell'apposito foro.
2. Far combaciare la leva "A" con la parete liscia della levetta "B".
3. Fissare la leva di tappaggio "A" sulla levetta rossa "B" munita di vite e dado.



Vantaggi


- Non “pizzica” il sughero.
- Non riduce la lunghezza del sughero durante il montaggio.
- Non altera la struttura alveolare del sughero.

Consigli

- Utilizzare tappi paraffinati.
- Impugnare i manici alle estremità.
- Tappare utilizzando come base d'appoggio il pavimento.



“GILDA” CORKER FOR NATURAL CORKS



Components and material composition

- Register.
- Nylon central body.
- 4 movable jaws.

Packaging

- Master: 20pcs in a box of 51x37,5x26,5

Use

For corks with a maximum diameter of 24mm.

Instructions of use

1. Turn the corker so that the lever will be under it, to avoid the ejection of the corker.
2. Distance the handles to enlarge the space where the cap will then be inserted.
3. Pull upwards the lever to make room for the cork.
4. Insert the cork.
5. Tighten the handles well.
6. Turn the corker.
7. Place on the bottle.
8. Lower the lever with conviction.

Assembly instructions

1. Insert the plunger “C” inside the corresponding hole in a single blow.
2. Turn the lever “A” to meet the smooth side of the lever “B”.
3. Fix the capping lever "A" on the red lever "B" supplied with screw and nut.



Advantages

- It doesn't "pinch" the cork.
- It doesn't reduce the length of the cork during corking.
- Does not alter the alveolar structure of the cork.

Advices

- Use moistened or paraffin-treated corks.
- Grip both handles at the end.
- Stand the bottle on the floor when corking.